

TABELLA POTENZA E COPPIA

Giri Motore	Hp	kW	Kgm
3000	15,6	11,48	3,72
3200	17,28	12,72	3,87
3500	20,3	14,94	4,15
4000	25,6	18,84	4,58
4500	31,5	23,18	5,01
5000	36,65	26,97	5,23
5500	41,8	30,76	5,44
6000	45,6	33,56	5,44
6200	47,12	34,68	5,44
6500	47,45	34,92	5,23
6700	45,6	33,56	4,87

