

**TABELLA POTENZA E COPPIA**

Giri Motore	Hp	kW	Kgm
3000	9	6,62	2,15
3500	11,2	8,24	2,29
4000	12,8	9,42	2,29
4500	14,4	10,6	2,29
5000	16,5	12,14	2,36
5500	18,7	13,76	2,36
6000	21	15,46	2,51
6500	22,75	16,74	2,51
7000	24,5	18,03	2,51
7500	25,5	18,77	2,43
7800	24,9	18,33	2,29

